







**Desktop Computer Projection** - Please follow the steps **1** to **4** as shown



**Laptop Computer Projection** - Please follow the steps **1** to **5** as shown



Switch on the notebook power and waiting for a steady "Windows" display



Switch display to Projector

**DVD/VHS Projection** - Please follow the steps 1 to 2 as shown

Step 1: MAIN MENU - EQUIPMENT CONTROL. The 'PROJECTOR ON' button is highlighted with a yellow arrow and a green circle labeled '1'.

Step 2: PROJECTOR SOURCE SELECT. The 'DVD/VCR' button is highlighted with a yellow arrow and a green circle labeled '2'.

DVD Projection: A yellow oval labeled 'DVD Projection' has a yellow arrow pointing to the 'DVD' button in the DVD/VCR CONTROL PAGE.

VHS Projection: A yellow oval labeled 'VHS Projection' has a yellow arrow pointing to the 'VCR' button in the DVD/VCR CONTROL PAGE.

The DVD/VCR CONTROL PAGE includes buttons for DVD, VCR, REW/SKIP-, F.F./SKIP+, DISK MENU, STOP, EJECT, PLAY/STILL, AUDIO, SUB-TITLE, ENTER, RETURN, and volume controls (VOL+, VOL-, VOLUME MUTE).

**External AV Projection** - Please follow the steps 1 to 3 as shown

Step 1: MAIN MENU - EQUIPMENT CONTROL. The 'PROJECTOR ON' button is highlighted with a yellow arrow and a green circle labeled '1'.

Step 2: PROJECTOR SOURCE SELECT. The 'AV-AUX' button is highlighted with a yellow arrow and a green circle labeled '2'.

Step 3: A photograph of the projector unit with a yellow oval and a green circle labeled '3' highlighting the AV input ports on the front panel.

**Projection Off** - Please follow the steps 1 to 2 as shown

Step 1: PROJECTOR SOURCE SELECT. The 'PROJECTOR OFF' button is highlighted with a yellow arrow and a green circle labeled '1'.

Step 2: A confirmation screen with the text 'Are you sure turn off the Projector?' and 'Yes' and 'No' buttons. A yellow arrow and a green circle labeled '2' point to the 'Yes' button.

A text box states: 'To save energy, please always switch off "video projector" after use.'

Remarks: After switching off the Video Projector, it needs 3 minutes to cool down before it can be switched on again