



User Manual

For Audio-visual Control System


Single Projection Classroom - M4023 and M4024

at Run Run Shaw Creative Media Centre

TABLE OF CONTENTS

1	INTRODUCTION OF AV TOUCH SCREEN CONTROL PANEL.....	2
2	OPERATION PROCEDURE OF DISPLAYING IMAGE FROM SOURCES.....	3
2.1	Way to display image from PC.....	3
2.2	Way to display image from DVD/VCR.....	4
2.3	Way to display image from Blue-ray player.....	5
2.4	Way to display image from Laptop.....	6
2.5	Way to display image from external AV equipment.....	7
3	OPERATION PROCEDURE OF PROJECTOR CONTROL.....	8
4	OPERATION PROCEDURE OF MICROPHONE ON/OFF.....	9
5	OPERATION PROCEDURE OF VOLUME CONTROL.....	10
6	OPERATION PROCEDURE OF SYSTEM SWITCH OFF.....	11


1 INTRODUCTION OF AV TOUCH SCREEN CONTROL PANEL



- | | |
|------------------------------|---|
| 1. System On | Turn on the system |
| 2. System Off | Turn off the system |
| 3. PC | Display the image signal from desktop computer |
| 4. Blue-ray player | Display the image signal from Blue-ray player |
| 5. DVD/VCR | Display the image signal from DVD/VCR disc player |
| 6. MIC ON/OFF | Microphone ON/OFF |
| 7. Laptop | Display the image signal from laptop computer |
| 8. Aux/Audio | Select external AV input |
| 9. DVD Control | Basic operation control DVD |
| 10. Screen Control | Control the screen up & down |
| 11. Auto image adjust | adjust the image automatically |
| 12. Volume Control | Control the sound level for video signal source |
| 13. System On | Turn off the system |

2 OPERATION PROCEDURE OF DISPLAYING IMAGE FROM DIFFERENT SOURCE

2.1 Way to display image from PC



- Power on the desktop computer first.



- Press the “ON” button to turn the system on.




- Press the “PC” button on the touch screen.


2.2 Way to display image from DVD



- Press the **“ON”** button to turn the system on.




- Press the **“DVD/VCR”** button on the touch screen.



- It will then direct you to the **“DVD/VCR”** control page for basic operations.


2.3 Way to display image from Blue-ray player



- Press the **“ON”** button to turn the system on.




- Press the **“Blue-ray player”** button on the touch screen.



- It will then direct you to the **“Blue-ray player”** “control page for basic operations.


2.4 Way to display image from Laptop



- Connect the laptop with VGA and audio cable.




- Press the **“ON”** button to turn the system on.



- Press the **“LAPTOP”** button on the touch screen.

2.5 Way to display image from external AV equipment



- Connect the external device with video and audio cable.




- Press the **“ON”** button to turn the system on.




- Press the **“AUX/Audio”** button on the touch screen.

3 OPERATION PROCEDURE OF PROJECTOR CONTROL




- Press the “**AUTO IMAGE**” Button to enter the adjust project image automatically.



- You can choose the “**screen up/down**”, to control the screen manually.

4. OPERATION PROCEDURE OF MICROPHONE ON/OFF




- Press the “**MIC**” Button to turn on the microphone.

- Press the “**MIC**” Button again to turn off the microphone.

-

5. OPERATION PROCEDURE OF VOLUME CONTROL



The image shows a black Extron remote control, model MLC 226 IP DV+. The volume control section is highlighted with a yellow circle. It includes a speaker icon, a red 'MUTE' indicator, and a rotary volume knob with green and red markings. Other buttons include 'ON/OFF', 'SCREEN UP/DOWN', 'AUTO IMAGE', 'PC/LAPTOP/BLU-RAY', 'VCR/DVD/AUX AUDIO/MIC', and a 'DVD & VCR CONTROL' section with 'TITLE', 'MENU', 'ENTER', 'TV/VCR', 'PREVIEWS', 'PLAY', 'NEXT-PAGE', 'PAUSE', and 'STOP' buttons. The Extron logo is in the bottom left and 'MLC 226 IP DV+' is in the bottom right.

- Adjust your desire volume level.

6. OPERATION PROCEDURE OF SYSTEM SWITCH OFF



- Press the **“OFF”** Button to turn off the system.