


City U
Monterey Plaza
MPL-2312

User Manual of AV Equipment

Smart Board Display Source

- A) Notebook (Notebook computer)
- B) HDMI Input (Use HDMI devices)
- C) USB-C Input (Use USB-C devices)
- D) Wireless Presentation for Apple Device
- E) Wireless Presentation for Windows & Android
- F) Smart Board Built-In PC
- G) Blank (Video Mute)
- H) Devices Control
- I) Smart Board Volume Control
- J) Ceiling Speaker Volume Control



Operation procedure of the HDMI Input

- 1) Press “HDMI ” button
- 2) Connect the other HDMI devices using HDMI cable



HDMI



Operation procedure of the USB-C Input

- 1) Press “USB-C” button
- 2) Connect the USB-C devices to USB-C cable



USB-C



Operation procedure of wireless presentation for Apple Device

- 1) Press “Wireless Presentation (Apple Device)” button
- 2) Use Screen Mirroring or AirPlay to connect Apple device



Apple Device





Operation procedure of wireless presentation for Microsoft & Android Device

- 1) Press “Wireless Presentation (Microsoft & Android)” button
- 2) Use Screen Mirroring to connect Microsoft & Android device



Microsoft & Android Device






Devices Control

Press A “Devices Control” button to “Devices Control”



- | | |
|--------------------------|-------------------|
| B) Smart Board Power On | D) VC Power On |
| C) Smart Board Power Off | E) VC Power Off |
| | F) VC Volume down |
| | G) VC Mic mute |
| | H) VC Bluetooth |
| | I) VC Volume down |



Lighting Control

Press A “Lighting Control” button to “Lighting Control”

- | | |
|------------------|------------------|
| B) All Light On | F) Preset mode 3 |
| C) All Light Off | G) Preset mode 4 |
| D) Preset mode 1 | |
| E) Preset mode 2 | |



System OFF

- A) System Power off
- B) Confirm Power off
- C) Cancel Power off

For IT or AV support, please contact the CSC Service Desk at 3442-8340